



Thank you for purchasing HOBBYWING PLATINUM 260A ESC! Please read this declaration carefully before use, once you start to use, we will assume that you have read and agreed with all the content. The brushless power system can be very dangerous and any improper use may cause personal injury or damage to the ESC and related devices, so please strictly follow the instruction during installation and use. Because we have no control over the use, installation or maintenance of the product, no liability may be assumed for any damages or losses resulting from the use of the product. We do not assume responsibility for any losses caused by unauthorized modifications to our product. Besides, we have the right to modify our product design, appearance, features and usage requirements without notification. We, HOBBYWING, are only responsible for our product cost and nothing else as a result of using our product. Regarding the possible semantic difference between the two versions of declarations, for users in mainland China, please take the Chinese version as standard; for users in other regions, please take the English version as standard.

HW-SMA052DUL-A0


Warnings

- Before using this product, read the instruction manual carefully. Ensure that the equipment is used appropriately to avoid damaging the ESC. The wrong usage will overheat the motor and may damage the electric
- It is important to ensure that all wires soldered are properly secured to avoid short circuits from happening. A good soldering station is recommended to do such a job to avoid overheating the circuit board as well as to ensure connectors
- Even though the product has relevant protective measures, always use it in a safe manner in accordance with the operating environment noted in the manual (e.g., voltage, current, temperature etc). • Always remember to disconnect the battery each time after using it. Failure to do so will cause the battery to be completely discharged, resulting in an unpredictable danger

02 Specifications

Model	PLATINUM 260A HV SBEC V5	PLATINUM 260A HV OPTO V5			
Continuous/Peak current	260A / 400A				
Input voltage	6-14S LiPo battery				
BEC	Switched-Mode BEC; output voltage 5-12V adjustable (adjusted 0.1V); output current cont. 10A, Peak 30A	No BEC			
Input/Output wires	1 x black and 1x red 8AWG silicone wires / 3 x black 10AWG silicone wires				
Independent parameter programming interface	Connect LCD program box or OTA module, or to power the cooling fan				
LED light	Display the statuses and fault alerts				
Size/Weight	89 x 50 x 34mm / 297g (With wires)	89 x 50 x 34mm / 287g (With wires)			
Mounting holes	M3, 39 x 98mm				
The scope of application	700-800 class electric helicopters (main rotor length 700-880mm), or fixed-wing aircrafts				

03 User Guide



① BEC output wire (red, brown): The additional BEC output wire is plugged into the receiver battery dedicated channel or any available channel. (For better BEC power output, it is recommended to insert the BEC cable into a battery-specific channel or any available channel)

② RPM signal wire (yellow): electrical RPM output line of the notor needs to be connected to the RPM in of an external device (such as a Flybarless system gyro).

(3) Throttle signal wire (white, red, black): Insert into the receiver throttle channel. Depending on the receiver type, the white wire is to transmit the throttle signal, whereas the red and black lines are parallel to the output of the internal BEC (e.g. the BEC voltage output wire and ground wire)

Normal boot process

the throttle stick to the lowest

Turn on the transmitter and push

Throttle stick calibration operation method ESC connect battery,

motor will sound "J

123", indicating that

power turned on is

normal

The ESC is connected to the battery, the

indicating that power turned on is norma

motor will sound off with "\$123".

Then motor will sound off with a "beep-beep indicating calibration for the highest point is successful.

Next, push the throttle stick to seconds, and wait 1 second for the throttle lowest point to be calibrated successfully..

sounded off to indicate the number of lithium batteries.

Finally, a "beep" tone indicates that the system is ready to take off at any time

Finally, a long "beep" tone indicates that the ESC self-check

is complete and the motor can



Turn on the

transmitter and push

the throttle to the

100% TH point


• The ESC default throttle range is 1100µs-1940µs (Futaba standard). The throttle range should always be re-calibrated for the first time or when the transmitter has been replaced. • Before calibration, always have the throttle curve set to default. Ensure that the throttle value corresponds to the highest point(100%) of the remote control throttle and the lowest

04 ESC programming and Data checking



• The ESC parameters can be programmed specifically to meet different flight needs • The ESC will be able to record the calibration speed of the current flight (only in storage Governor Mode), the minimum voltage, maximum temperature and other information. If you want to check the data after a flight, please do not disconnet the power from the battery or the information can't be sayed. Connect LCD program box or OTA module to view.


Use Multifunction LCD program box to program ESC parameters (need to purchase separately)



A "beep" tone is sounded off to indicate the number of

- Connect the ESC to LCD program box as shown above, and then connect the battery to
- The current firmware version will be displayed once the power is turned on.
- Press "ITEM" to browse through the parameters, and press "VALUE" to change the settings; · Press OK to save the settings;
- Repeat step 3) and step 4) to modify the settings of other parameters • Once completed, disconnect the ESC from the battery and unplug the wire between the ESC and LCD program box. Power up again and you are ready to run the new settings. Note: Any parameter changes will require the ESC to be re-powered to take effect.
- 3. Check the ESC running data
- Do not disconnect the ESC after the flight, then connect the ESC and LCD program box as shown above:
- The version of the current firmware will be displayed once you have connected the LCD program box to the ESC.
- Press "ITEM" key continuously, and after browsing the parameters of the ESC, the status data (minimum voltage, maximum temperature, maximum speed, etc.) of the ESC

Use OTA Module to program the ESC parameters (need to purchase separately)



- Connect the ESC and OTA module as shown above, then connect the battery to the ESC.
- . Turn on your phone's Bluetooth and connect to the OTA module. Once connected, open "HW Link" software from the mobile phone and click on "connection" to make changes to the parameters, view data records and perform other
- Once completed, disconnect the ESC from the battery by switching off and unplugging the OTA module. Power up again and you are ready to run the new settings.

3. Check the ESC running data

- Do not disconnect the ESC after the flight, then connect the ESC and OTA modules as shown above:
- Turn on your phone's Bluetooth settings and connect to the OTA module.
- Open "HW Link" and click on the icon to connect. Click on "data record" to select and "Airplane" to view the record data.

05 Programmable parameters and instructions

	9									
Programmable parameters and parameter values										
	Item Value									
1	Flight mode	Fixed-wing	Helicopter extern	al Governor	*Helicopter Express Governor	Helico	pter store Governor			
2	LiPo cells	*Auto Calculation	65	85	105	125	145			
3	Low-Voltage Cutoff Type	*Soft Cutoff			Hard Cutoff					
4	Cutoff Voltage	Disabled	2.8V-3.8V (Default *3.0V)							
5	BEC Voltage	5-12V(Default: *6.0V)								
6	Response time	4-25(Default *15)								
7	Governor parameter P	0-9(Default *5)								
8	Governor parameter I	0-9(Default *5)								
9	Auto Restart Time	0-90 seconds(Default *25 seconds)								
10	Restart acceleration time	1-3 seconds(Default *1.5 seconds)								
11	Brake Type	* Disabled			Normal brake					
12	Brake Force	0-100%(Default 0%)								
13	Timing	0°-30°(Default 25°)								
14	Motor direction	*CW			CCW					
15	Active Freewheeling	*Enabled			Disabled					
16	Start-up force	1-7 (Default *3)								

16 Start-up force 1-7 (Default *3) "*" in the form below indicate factory defaults.

1. Flight mode

1.1. Fixed-wing mode: Suitable for fixed-wing aircrafts. In this mode, the throttle has to be more than 5% (including 5%) to start the motor and the throttle response is rapid.

1.2. Helicopter External Governor mode: Suitable for helicopters without any governor or helicopters using external governors. The throttle has to be higher than 5% (including 5%) before starting the motor. After the slow start is completed, the motor will start off with a smoother manner, followed by a faster throttle response accelerated to the current throttle value

1.3. Helicopter Express Governor mode: Suitable for helicopters flying at a fixed headspeed. The throttle has to be higher than 40% (including 40%) before starting the motor. In the soft start process, the motor starts in an ultra-smooth

acceleration to complete the speed calibration

1.4. Helicopter Store Governor mode: Suitable for helicopters flying at a fixed headspeed. The throttle in this mode has to be more than 40% (including 40%) before starting the motor. The motor starts in an ultra-smooth manner. After the soft start, the governor will be activated.

The number of battery cells can be detected automatically, or set manually. Select Auto-calculation to calculate the number of battery cells automatically. Errors on battery cells will be detectable during self-test and can be adjusted

*Note that speed calibration must be done each time when other modes are switched to this mode 2. LiPo cells

accordingly

3. Low-Voltage Cutoff Type Soft Cutoff: The output power will be gradually reduced to 50% of the total power output after low voltage protection is triggered.

Hard Cutoff: Disconnect the power output immediately after low voltage protection is triggered.

2.8V-3.8V per cell with 0.1V step adjustability. For example, When using 6S lithium batteries, the protection voltage should be set by ×6. 5. BEC Voltage

The ESC is built-in with a BEC of 5-12V and has the capability to adjust 0.1v per step. 6. Response time

Adjust the response speed of the throttle in "helicopter Express Governor" or "store Governor". The higher the value, the slower the throttle response speed. 4-25 fully adjustable.

7. Governor parameter P This parameter is for controlling the ESC to compensate the amount of the motor speed during the process of maintaining the speed-governing effect; the higher the value, the bigger the amount; and vice versa. This function functions together with the Governor Parameter

8. Governor parameter I When the speed falls below, or exceeds the value set, the speed is compensated by the ESC. This parameter is used to resize the degree of rotation. Too large parameters will cause excessive make-up, and too small parameters will cause

insufficient replacement

This feature is only available in helicopter Express or Store Governor modes. It is the time set to push the throttle from more than 40% to 25% to 40% throttle range, and then push back more than 40%. The parameter will not take effect when the throttle range is below 25% or between 25%-40% beyond the set time. The ESC will execute the "helicopter Express / storage fixed speed" modes of the default start-up process only if the throttle range is above 40%.

1-3 seconds, with 0.5 seconds step adjustability. This parameter controls the time required for the motor to accelerate from zero to full speed during a quick restart. (This is an auxiliary function and is only valid if the "time to turn off and land" function is valid)

11. Brake type

Normal brake: This function will stop the motor from braking during operating according to the value set on the braking force.

The greater the value, the shorter the time taken for the motor to come to a standstill. 0-100%, with 1% step adjustability. This function is only valid in normal brake mode 13. Timing

12. Brake Force

This item is for adjusting the ESC timing. It's adjustable between 0 and 30° with the step of 1°.

This item is for setting the rotation direction of the motor, and it's "CW" by default. After connecting the motor to the ESC, (if the motor rotates clockwise); when setting this item to "CCW", the motor will rotate counterclockwise; (if

the motor rotates counterclockwise), when setting this item to "CCW", the motor will rotate clockwise 15. Active Freewheeling This item can be enabled or disabled when the "Flight Mode" is set to the "Fixed-wing" or "Heliconter (External Governor) mode: it's fixed at "Fnabled" when the "Flight Mode" is set to the "Heliconter (Elf Governor)" or "Heliconter (External Gove

(Store Governor)" mode. With this item enabled, the throttle linearity will be great.

This item is for adjusting the start-up force of the motor (during the start-up process). The higher the value, the larger the start-up force. It's adjustable between 1 and 7.

06 Speed Governor Function

Explanation for the ESC Speed-governing

Establish the "Motor RPM-Throttle Amount Curve" via the speed standardization, and then set the throttle amount to some fixed value on the transmitter, in that condition, the motor will output the RPM corresponds to the throttle amount and keep rotating at that speed.

• In the "Helicopter (Express Governor)" mode, the ESC won't save the "Motor RPM-Throttle" curve after it's disconnected from the battery, so every time when the ESC is connected to the battery, it will standardize the speed, otherwise you cannot use the speed-governing function normally. In this mode, due to the differences like batteries' discharge capacities, the standardized RPM is a little different every time. In consequence, at the same throttle amount, the RPM may be a bit different when using different batteries, but this won't affect the speed-governing effect.

• In the "Helicopter (Store Governor)" mode, the ESC will save the "Motor RPM-Throttle" curve after the speed standardization. So after adjusting to this mode from any other mode, you need to standardize the speed when the ESC is connected to the battery for the first time and you needn't standardize the speed again after disconnecting the ESC from the battery first and then connecting it to the battery again. If adjusting to any other mode from this mode and saving the "Motor RPM-Throttle" curve, and then adjusting back to this mode, the "Motor RPM-Throttle" curve saved by the ESC will be cleared, and you need to standardize the speed once again. If your ESC remains in this mode in future, then it will always carry out its operation as per the saved "Motor RPM-Throttle" curve. When standardizing the speed for the first time, we recommend using a battery in good condition. After the RPM standardization, change another battery with the same number of cells to fly your aircraft. At the same throttle amount, the RPM should be consistent with the RPM of the first flight

RPM Standardization

1) The principle of RPM Standardization

During the RPM standardization, the ESC will establish a "Motor RPM-Throttle" curve by itself based on the actual battery voltage and the actual KV rating of the motor, Therefore you need to standardize the speed with a fully charged battery, and ensure the main blade pitch is 0° (in order to make the helicopter not take off)

In general, people use the default "Throttle Curve & Pitch Curve" of the transmitter (as shown below) when they standardize the speed.

Attention! Please ensure the main blade pitch is 0° and the throttle amount is above 40% (we recommend using 50%) when standardizing the speed

• We recommend using the default "Throttle Curve & Pitch Curve". (If you don't want to use the default setting, then please ensure the throttle amount is 50% and the main blade pitch is 0° when the motor rotate • Turn on the transmitter, move the throttle stick to the bottom position and then wait for the ESC completing the self detection.

• If you've set the "throttle cut" function, please lock the "throttle cut", and then move the throttle stick to the 50% position and then unlock the "throttle cut". If there is no "throttle cut", then you can move the throttle stick to the 50% position directly.

• The ESC drives the motor to rotate, the main blades start to accelerate slowly (because the main blade pitch is 0°, so the helicopter won't take off, but you still needs to be careful), you need to wait for the acceleration completing and the speed getting stable, and then lock the "throttle cut" or move the throttle stick to the bottom position

• The ESC will stop driving the motor, the main blades start to slow down and then stop rotating • The RPM standardization completes

Attention! Please calibrate the throttle range before the RPM standardization. There will be no need if you've carried out the ESC/Radio Calibration when the first time you used this the ESC or you didn't restore the settings to factory defaults after the calibration (changing the transmitter & receiver is an exception)

3 How to Set the Governor

• The best throttle amount (set in the Helicopter "Store Governor" mode) of the ESC ranges from 70% to 90%, so please try to set the throttleamount (set in the Helicopter "Store Governor" mode) within this range. A low throttle amount (set in the Helicopter "Store Governor" mode) will make the ESC always function inefficiently; while a high throttle amount (set in the Helicopter "Store Governor" mode) will leave the ESC a very small compensation space, then compensation insufficiency issue may happen and cause (speed decrease) problem when the load is high. In that case, we recommend changing the motor or drive gear ratio (you need to re-standardize the speed after you change the motor or drive gear ratio). • In the "Helicopter (Store Governor)" mode, if fly your aircraft with a low performance battery after standardizing the speed with a high performance battery may cause damage to the low




- performance battery. • In "Helicopter (Store Governor)" mode, different battery packs can bring the same stable RPM only if they have the same cell count. This won't change even when you change the battery pack. However, battery packs with different cell count don't have the same effect. For instance, in "Helicopter (Store Governor)" mode, you can't use a 4S to calibrate the motor RPM and then use a 6S to drive the motor, hoping it can run at the same RPM.
- You can decide the control feel via adjusting Governor Parameter P/I. In "Helicopter (Store Governor) or Helicopter (Express Governor)" mode, connect your ESC to a smart phone or PC,
- 1. In "Helicopter (Store Governor)" mode, you can check the standardized speed (Max. RPM) and needn't standardize the speed every time when the ESC is connected to the battery as in the "Helicopter (Express Governor)" mode
- so it's more convenient. We recommend using this mode in the condition that you're using fixed motor, drive gear ratio and battery (with same cell count). In this mode, only if the drive gear ratio is accurate, the main blades RPM corresponds to the throttle amount (set in the Helicopter "Store Governor" mode) that you will get will be accurate as well. About how to "set the speed-governing function" in this mode, let's take an example .1. • In "Helicopter (Store Governor)" mode, connect the ESC to the LCD program box or WIFI Express module when the RPM standardization

completes, and then find the record (as shown below) as per the instruction about the " data checking" process The value shown in the image is just an example, pleas take the value actually displayed on your LCD program box as standard. This value is

the max. electrical RPM and the motor can reach at the 100% throttle.

• Take a helicopter with single reduction gear unit as an example, the motor poles is 10, the motor drive gear is 13T and the main drive gear is 120T (that the drive gear ratio is 9.3), and then you can get the main blades' RPM at the 100% throttle.

Formula: Main Blades' RPM (at the 100% throttle)=Max. RPM÷ (Motor Poles ÷2)÷Drive Gear Ratio



The Main Blades' RPM (at the 100% throttle) in the example is: 157*1000÷(10÷2)÷(120÷13)≈3400 RPM If the Main Blades' RPM needs to remain at 2700RPM during the 3D flight process, then you need to set the throttle amount time, when you fly your helicopter, let it take off in the "Normal" mode first and then switch to the "IDLE1" mode directly, then your helicopter can start the 3D flight with 80% throttle amount (that's the standardized speed of Notes: in general, you can set and save 2/3 sets of throttle curve IDLE settings on a high quality transmitter (and you need to adjust the main blade pitch of each set of IDLE setting as per the actual demand), and switch between

these settings during the flight and have the different throttle amount (set in the Helicopter "Store Governor" mode) to meet the different RPM demands (i.e. when setting IDLE1 to 70%, IDLE2 to 80%, IDLE3 to 90% in the

way as explained earlier, then you will have three different throttle amounts (set in the Helicopter "Store Governor" mode) to meet different flight demands 2. In the "Helicopter (Express Governor)" mode, you are not allowed to check the Max. RPM, so you need to set the transmitter in advance and check the main blades' RPM with the help of some external device (like RPM viewer) and then decide the throttle amount that you need to set. Here you can calculate the throttle amount roughly. For example, if the KV rating of the motor is 480KV, the battery is a 12S LiPo, the motor drive gear is 13T and the main drive gear is 110T, then the main blades' RPM is: KV Rating × Battery Voltage +Drive Gear Ratio (480*12*4.2*13+110~2850). So if you want your motor to rotate at the speed of 2150RPM, then the throttle mount is: 2150÷2850≈0.75 (that is 75%), and then you adjust it accordingly as per your preference or the data you read on the RPM viewe

07 Warning Tones and Protection

1. LED indicators and warning notes

Protection	Tone	LED indicator	Instruction
The input voltage is abnormal	"BB, BB, BB, BB"	Red LED, followed by the tone	The input voltage is not within the input voltage range
Throttle signal loss	*B,—,B,—,B,—	Red LED, followed by the tone	The throttle signal input was not detected
The throttle stick is not moved to the 0% position.	"B, B, B, B"	Red LED, followed by the tone	The throttle value is not at 0% throttle
The throttle range is too small	"B, B, B, B"	Red LED, followed by the tone	When calibrating the throttle stroke, set the throttle travel too small
Temperature protection	"BB, BB," or "BBB, BBB"	Red LED, followed by the tone	The internal temperature of the ESC exceeds the protection temperature
Low voltage protection	"BBBB, BBBB"	Red LED, followed by the tone	The operating voltage is lower than the set protection voltage
Current protection	None	Red is always bright	The operating current is higher than the set current

2. Protection function description

The ESC enters a protective state once the input voltage detected is not in the operating range. Prompting LED light to flash.

Start-up protection

The start-up protection will be able to detect the motor speed from when the speed stops rising or the rising speed is unstable. If the throttle input is less than 15%, the ESC will try to restart automatically; (This may occur due to; Poor contact between the ESC and motor connections, individual output wires, faulty motor, propellers blocked by other objects, Binding gears, etc.)

When the operating temperature of the ESC has exceeded 110 degrees Celsius, power will be gradually reduced for safety, but will not be turned off. There will still be up to 50% of power, to ensure that the motor has the power to land. After the temperature drops, the ESC will gradually be restored back to maximum power. The ESC temperature must not exceed 70 degrees or it will not work. Prompting LED light to flash (above is the soft-off protection mode, if you choose hard-off, cut off the power directly)

When the throttle signal is lost for more than 0.25 seconds, the output is immediately switched off to avoid further damage due to the propeller rotating at a high speed. Once the signal has been restored, the power output will be restored.

When there is a sudden surge of current, power will be cut off and will be restarted. If the load is still abnormal after the restart, the power will be completely cut off.

Low voltage cutoff protection

When the operating voltage of the ESC has exceeded the protection voltage set, power will be gradually reduced for safety, but will not be turned off. There will still be up to 50% of power, to ensure that the motor has the power to · Over-current protection

Overloading protection

The current will be cut off immediately once the set value has been breached.