



If AXE ESC uses **01-00.2.01** firmware, the throttle stroke cannot be set if the throttle ratio of remote control is not 5:5(e.g. 7:3). So please check whether the throttle ratio of remote control is 5:5 or not, when your AXE ESC firmware is the above version and cannot set throttle stroke. If not, please set to 5:5 to test. Here will explain how to set the throttle ratio of remote control based on the two kinds of remote control on the market.

SANWA MT-4S



- Step 1: Choose **【SYSTEM】** menu



- Step 2: Choose **【TH TYPE】** submenu



- Step 3: Choose "F70 : B30" value, change it to "F50 : B50"



TRAXXAS TRX-4 original TQi remote control

The throttle ratio setting of remote control can be switched by the toggle switch shown by the arrow in the following figure.



Note: For other type of remote control please as per the above method or its instruction to set. If your remote control does not have throttle ratio setting, please use other firmware of the ESC. We will update firmware as soon as possible to support 7: 3 ratio remote control and update APP to amend problem. Sorry to cause you any inconvenience!